

# TZ-TempU02 Disposable USB Temperature Data Logger Testing Guidance



## 1. Workable device

After getting the device, please don't tear the plastic bag but to quick press the button. If "ALARM" led and "OK" led flash at the same time, it indicates workable device. Otherwise, it's failure one and won't operate any more.

## 2. Start

For workable device, please press and hold the button over 3 seconds until "OK" led brightens to start logging. It can be confirmed through either situation below:

- 1) Quick press, then neither "ALARM" led nor "OK" led brightens
- 2) Either "ALARM" led or "OK" led flashes every 10 seconds

## 3. Stop

Logging can be stopped by pressing and holding the button for more than 3 seconds and the "ALARM" led will brighten in 3 seconds. To ensure whether logging is stopped, you can quick press the button and observe led status. If only one led flashes, it's a successful stop.

## 4. PDF report input

Tear or cut off the plastic bag and insert the logger into an available USB port on a PC. "OK" led and "ALARM" led will flash in turn when PDF is generating. When PDF has generated, the "OK" led will brighten until pull out from the USB port and the PC will pop up a hard drive named "TZONE", which can be opened to obtain PDF files.

## Notes:

- 1) If the logger is stopped during the status of start delay, there will be A PDF Report but no data.
- 2) Loggers will be stopped by inserting it into PC port without button operation.
- 3) It's disposable device and can't be reused after being stopped.

Please follow the test process strictly. If you have any questions, please contact us.